

PRXF -LV

Installation Precautions



DO NOT apply cement from **above** regulator.



DO apply cement from **below** regulator.



Once cement has set, install PRXF/pipe assembly in any orientation downstream of control or shut-off valves.

NEVER ALLOW CEMENT TO DRIP INTO REGULATOR!

- Make sure **FLOW ARROWS** on the regulator match the direction of system flow.
- To remove PRXF after installation, use of a union is recommended.
- Inlet/Outlet Configuration: 3" solvent weld socket x socket.

Precauciones de Instalación del PRXF -LV



No aplique cemento encima del regulador.



Aplique cemento por debajo del regulador.



Una vez que se haya secado el cemento en ambos lados, instale el PRXF después de la válvula de bloque.

NUNCA PERMITA QUE EL CEMENTO GOTEE DENTRO DEL REGULADOR!

- Asegúrese de que las flechas en el regulador sigan la dirección del agua.
- Para remover el PRXF después de haber sido instalado, se recomienda el uso de uniones.
- Configuración: salida y entrada de 3" de pegar.