

CAUTION

DO NOT DISASSEMBLE THE PRESSURE REGULATOR!
Each regulator contains a compressed spring
which could cause personal injury if released.
Please have dealer return regulators to factory for repair.

The pressure regulator should be installed
downstream from all shut-off valves.

Direction of flow through pressure regulator must
be in the same direction as arrow shown on regulator.

ADVERTENCIA

¡NO DESARME EL REGULADOR DE PRESIÓN!
Cada regulador contiene un resorte que está retraído
y que podría causar un daño a la persona que lo desarme.
Por favor, devuelva los reguladores a su distribuidor local
en caso de que no esté trabajando adecuadamente.

El regulador de presión debe ser instalado
después de cualquier válvula de cierre.

La dirección del caudal a través del regulador debe ser en
la misma dirección de la flecha impresa en el cuerpo del mismo.